



Item no.	Product
41982	PondoVac 5
41983	GB PondoVac 5





Pos.	Item no. Product	Product	Item no. Spare part	Spare part	Number
1	41982	PondoVac 5 [INT]	44024	Spare ASM adjustable handle PondoV.3/4/5	1
	41983	PondoVac 5 [GB]			
2	41982	PondoVac 5 [INT]	44014	Spare part motor head PondoVac 5	1
	41983	PondoVac 5 [GB]	44165	Motor section PondoVac 5	1
3	41982	PondoVac 5 [INT]	44004	Spare filter foam PondoVac Classic / 5	1
	41983	PondoVac 5 [GB]			
4	41982	PondoVac 5 [INT]	44001	Spare engage plate PondoVac Classic / 5	1
	41983	PondoVac 5 [GB]			
5	41982	PondoVac 5 [INT]	44020	Spare part debris bag with strap	1
	41983	PondoVac 5 [GB]			
6	41982	PondoVac 5 [INT]	44011	Spare part tank top PondoVac 5	1
	41983	PondoVac 5 [GB]			
7	41982	PondoVac 5 [INT]	44026	Spare part clamp PondoVac 3 / 4 / 5	1
	41983	PondoVac 5 [GB]			
8	41982	PondoVac 5 [INT]	44018	Spare part tank sealing PondoVac 5	1
	41983	PondoVac 5 [GB]			
9	41982	PondoVac 5 [INT]	43487	Extension hose PondoVac 5	1
	41983	PondoVac 5 [GB]			
10	41982	PondoVac 5 [INT]	44029	Spare part intake hose PondoVac 3/4/5	1
	41983	PondoVac 5 [GB]			
11	41982	PondoVac 5 [INT]	44013	Spare part intake PondoVac 5	1
	41983	PondoVac 5 [GB]			
12	41982	PondoVac 5 [INT]	44003	Spare suction pipe PondoVac transparent	1
	41983	PondoVac 5 [GB]			
13	41982	PondoVac 5 [INT]	44028	Spare suction pipe aluminium PondoVac	1
	41983	PondoVac 5 [GB]			
14	41982	PondoVac 5 [INT]	44005	Spare part debris bag PondoVac 3/4	1
	41983	PondoVac 5 [GB]			
15	41982	PondoVac 5 [INT]	44027	Spare universal nozzle PondoVac 125 mm	1
	41983	PondoVac 5 [GB]			
16	41982	PondoVac 5 [INT]	44025	Spare part surface brush PondoVac	1
	41983	PondoVac 5 [GB]			
17	41982	PondoVac 5 [INT]	44030	Spare part nozzle set PondoVac	1
	41983	PondoVac 5 [GB]			
18	41982	PondoVac 5 [INT]	44021	Spare part pump PondoVac 5	1
	41983	PondoVac 5 [GB]	44831	ASM pump PondoVac 5	1
19	41982	PondoVac 5 [INT]	44015	Spare part pump holder PondoVac 5	1
	41983	PondoVac 5 [GB]			
20	41982	PondoVac 5 [INT]	44012	Spare part tank bottom PondoVac 5	1
	41983	PondoVac 5 [GB]			
21	41982	PondoVac 5 [INT]	44016	Spare part c-cuppler PondoVac 5	1
	41983	PondoVac 5 [GB]			
22	41982	PondoVac 5 [INT]	44168	Spare part gasket C-coupler PondoVac 5	1
	41983	PondoVac 5 [GB]			
23	41982	PondoVac 5 [INT]	44023	Spare part wheel sleeve PondoVac 5	1
	41983	PondoVac 5 [GB]			
24	41982	PondoVac 5 [INT]	44022	Spare part wheel PondoVac 5	1
	41983	PondoVac 5 [GB]			
25	41982	PondoVac 5 [INT]	44019	Spare part base PondoVac 5	1
	41983	PondoVac 5 [GB]			
26	41982	PondoVac 5 [INT]	44017	Spare part check valve PondoVac 5	1
	41983	PondoVac 5 [GB]			

Pos.	Item no. Product	Product	Item no. Spare part	Spare part	Number
27	41982	PondoVac 5 [INT]	17232	Rubber part AquaMax Pro	1
	41983	PondoVac 5 [GB]			
28	41982	PondoVac 5 [INT]	16978	Clamp EC1	1
	41983	PondoVac 5 [GB]			