



Position	Spare parts	Part number
1	Integrated board (Heat&Cool)	2005030200059A56
2	Oval touch controller	2005020900011
3	Power filter plate	033092370000
4	Reactor (big)	041301110000
5	Electronic expansion valve	006121110001
6	4-way valve	2002010100014
7	Water flow switch	040060620000
8	Fan motor	032051640000
9	Full set of sensors	Z35043000400
10	Compressor	1201010300043
11	Titanium heat exchanger (Heat&Cool)	2001020100153
12	Evaporator	1202010200135
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	1203020300001
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010120000
20	Drainage kit	Z03991700000
21	Top cover	1220020103755
22	Front Panel	1220020302244
23	Right Up Panel	1220020302248
24	Back Panel	1220020302247
25	Bottom board	1220020103756
26	Back mesh board	1220020302246
27	Left mesh board	1220020302245