Aquascenic Installation Guide



110-230 V

DESCRIPTION

Aquascenic is a water treatment system and a controller for swimming pools. This water treatment combines hydrolysis and ionization. With the hydrolysis system we produce active agents such as oxygen, hydrogen peroxide, OH and ozone from fresh water with a slight charge of salt (around 1 g salt per liter). Like this, organic matter and pathogenic agents, present in the water, are oxidized and eliminated in the cell. As the water returns to the swimming pool the produced active agents reconvert into water and salt. The copper/silver (Cu/Ag) ionization flocculates the suspended particles, achieving exceptionally clear and transparent water as a result. In addition , the ionization reinforces the elimination of bacteria and algae. Aquascenic controls centrally all the components of your pool, ensuring an efficient interaction.



Electronic box

JUUU

@ 1

1 Hydrolysis

2 RCA flow detector

4 ON/OFF switch

3 Main connection 230 V



5 Fuse for device and cell 3.15 A6 Fuse relays 3.15 A





- 1 Ionization chamber (2 / 4 / 6 electrodes)
- 2 Copper/silver electrodes
- 3 Electrode nut
- 4 Electrode cable



Optional automatic controls



Metering and control of the pH of the water.



Metering and control of the redoX as check value of the free chlorine.



Metering and control in ppm of the free chlorine of the water.



Conductivity Metering and control of the conductivity of the water in Msiemens.



Temperature Temperature probe 0 - 100° C necessary to activate the filtration modes: heating / intelligent / smart.



Flow detector

Mechanic security flow switch. Stops the hydrolysis if there is no water flow.

2 SYSTEM INSTALLATION



Electrical consumption

Product	Maximum consumption	
HD 1	80 W	10 A
HD 2	120 W	10 A
HD 3	400 W	16 A
HD 4	680 W	16 A
HD 5	1000 W	25 A
HD 6	1020 W	25 A
HD 7	1500 W	25 A

* Filtration control by external timer



Filtration mode: "Manual/ON"

* Filtration control by internal timer

Relay FILTER PUMP

Filtration mode: See section 4.4

110-230 V 😳

INITIAL WATER ADJUSTMENTS

Water adjustments

- Adjust the alkalinity between 90 and 110 ppm's.
- **2** Adjust the pH between 7,2 y 7,5.
- **3** Adjust the chlorine between 1 y 1,5 ppm's.
- In case the water is supplied from a well: Shock chlorination with trichloroisocyanuric acid (2 kg / 50 m³ of water).

Conductivity adjustments

- In poorly conductive waters we recommend to add 1 kg of sodium chloride (NaCl) for every m³ of pool water.
- In pools which receive large amounts of strong sunlight, it's necessary to add 30 gr/m³ of stabiliser (isocyanuric acid).





4.4 Filtration ок +🕯 Hidrolysis Auto 🔊 ion Cu/Ag <u>1 01:00</u> On 02:00 Measures **2** 00:00 00:00 Filter cleaning 3 00:00 00:00 1 m Filter cleaning Filtratio 🌒 🖿 00:00:02 ++Intelligent 🛆 Turn on filtration pum Heating Turn off filtration pum 10°C Temperature 25°C Temperature 28°C Temp. min 💼 aut 🔊 💡 mar Temp. max. 25°C Off Ainimum 8 hours You can access Antifreeze On Off 1 01:00 02:00 Filter cleaning the display "Filter cleaning" from any 1 00:36 00:38 2 01:07 01:08 filtration mode. 2 01:07 01:08 3 01:09 02:00 Once selected this 3 01:09 02:00 Filter cleaning function, press the Filter cleaning OK key.

4.1 Filtration modes

4.2 Manual: Filtration can be switched ON and OFF manually. **4.3** Automatic (or with timer): In this mode the filtration switches ON/OFF according to 3 timers. The timers always work on daily bases.

4.4 Smart*: This mode uses, as a basis, the automatic or timer mode, with its 3 intervals of filtration, but adjusting the filtration time in function of the water temperature. For that reason 2 parameters of temperature are provided: The maximum temperature, from which on the filtration times will be the ones from the timer setting. The minimum temperature: below this value the filtration time will be reduced to 5 minutes, which is the minimum working time. Between these 2 temperatures the filtration times will climb linearly. There is an option to activate the antifreeze mode in which the filtration will start if the water temperature is below 2° C.

4.5 Timed heating with option of climatization*: This mode acts equally to the automatic mode, but besides it includes the option to work on a relay to control the temperature. The desired temperature is set in this menu, and the system works with a hysteresis of 1 degree (example: the setting temperature is 23° C, the system will activate itself when the temperature goes below 22° C and will not stop before it passes 23° C).

4.3 Filtration (continuation)

Clima OFF: The heating only works within the set filtration periods. Clima ON: Keeps the filtration working when the filtration period is finished if the water temperature is below the setting temperature. When the setting temperature is reached the filtration and the heating will stop and will not switch on till the next programmed filtration period.

4.6 Intelligent*: In this mode the user has 2 working parameters to guaranty the desired water temperature with a minimum of filtration hours: You select the desired water temperature and the minimum filtration time (minimum of 2 hours and

maximum of 24 hours). The device divides the selected "minimum filtration time" in 12 fragments which start up every 2 hours. If one of these fragments finishes, without the temperature reaching the desired level, the filtration/heating continues until the desired temperature is accomplished. In order to keep the filtrationelectricity-cost to a minimum, this additional filtration time is subtracted from the following fragments of the "minimum filtration time". The first 10 minutes of each fragment will not be subtracted. Example (see diagram): Minimum temperature = 28°C and minimum filtration time = 12 hours.



4.7 Filter cleaning mode (and pool cleaning by suction): Use the up/down keys to activate or deactivate the filtration pump. The device will inform about the elapsed time from the moment of activation or deactivation. Follow the instructions of the filter manufacturer to execute an adequate filter cleaning. * Note: Modes only visible if the option to use temperature and/or heating probe is activated in the "Installer Menu".



6.1 Auxiliary relays

6.2 It is possible to control up to 4 extra auxiliary relays (water features, fountains, automatic irrigation systems, built-in cleaning systems, air pumps for spas, garden lighting, etc.). This menu displays the relays which are still available on your device and allow configuration.

6.3 Manual mode (ON/OFF).

6.4 Automatic mode: ON/Off according to a timer. The timers can be configured with a frequency: Daily; Every 2 days; Every 3 days; Every 4 days; Every 5 days; Weekly; Every 2 weeks; Every 3 weeks; Everv 4 weeks.

minutes. Each time the selected key on the front panel is pressed, the relay will start up for the time programmed. This function is recommended for the timing of air pumps for spas.



5 SYSTEMS WITH redoX CONTROL

The redoX value advises us of the oxidation/reduction potential and is used to determine the level of water sterilization. The parameters or setpoints are the minimum/maximum accepted redoX levels before the titanium cell is connected/disconnected. Adjusting the ideal redoX level (setpoint) is the last step in the Aquascenic start up sequence. To find the optimum redoX levels for your pool follow these steps:

- Connect the pool filtration system (the salt in the pool must be adequately dissolved).
- 2 Add chlorine to the pool till a level of 1-1,5 ppm is achieved (approx. 1-1,5 gr/m³ of water). pH levels should be between 7,2 7,5.
- After 30 min. test the free chlorine levels in the pool (manual test kit DPD1) if the free chlorine level is between 0,8 1,0 ppm. Look at the redoX screen and memorize this level as the setpoint to CONNECT / DISCONNECT the hydrolysis cell.
- In the next day check free chlorine levels (manual test kit DPD1) and redoX. Raise / lower setpoint if necessary.
- **5** Remember to check the redoX set-point every 2-3 month and/or if the water parameters change (pH / temperature / conductivity).

MAINTENANCE

First days of maintenance

During the first 10-15 days your pool system will require more attention and the following care:

- During the use of the lonizer it is important not to exceed copper concentrations of more than 0,5 ppm in the water. For this reason it is mandatory to measure copper levels during the initial phase (first weeks) and to readjust copper production between 20 to 50 after establishing 0,5 ppm copper in the water. Furthermore the time limitation Pr 10 (see section "4.2 ion Cu/Ag") has to be initiated.
- Make sure the pH remains on the ideal level (7,2 7,5). If the pH is unusually unstable and uses a lot of acid, check the alkalinity (recommended levels between 80 120 ppm).

3 The pool must be vacuumed and the skimmers cleaned whenever necessary to ensure perfect water conditions.

REMEMBER that the system requires a certain amount of time to adapt to your swimming pool and will require additional chemicals during the first 3-5 days.

Cleaning the titanium cell

If necessary, carry out a monthly visual inspection. To clean the cell:

Remove the cell from its support (after turning off the filtration system and closing off the necessary valves).

Place the cell for no more than 10 minutes in 15% hydrochloric acid (1,5 I of acid for each 8,5 I of water).

3 Once the incrustations have softened remove with a hose to complete cleaning the cell.

DO NOT USE METALIC OR SHARP OBJECTS TO REMOVE INCRUSTATIONS. Scratching the edges or surface of the cell will make it vulnerable to chemicals, deteriorate the cell and cancel the guarantee.

Fortnightly checks

FREE CHLORINE: 1,0 - 2,0 ppm pH: 7,2 - 7,5 Cu CONCENTRATION: 0,3 - 0,5 ppm

Monthly checks

TOTAL ALKALINITY (TAC) pH: 80 - 120 ppm SALT CONCENTRATION: 800 - 1.500 ppm

CYANURIC ACID: 30 - 50 ppm TITANIUM CELL: Visual inspection to detect incrustations.

General maintenance

The pool must be vacuumed as usual and the skimmers emptied whenever necessary.

- FILTER BACKWASHING: The system requires only occasional filter backwashing; once every 20 days should be sufficient (providing the filter pressure does not exceed 1 bar, in which case a backwash may be necessary).
 VERY IMPORTANT: Make sure the cell is off while cleaning the filter. If the system controls the filtration pump, use the option "filter cleaning" of the programmed filtration mode. See section 4.4 Filtration (Filter Cleaning).
- 3 ADDING NEW WATER: Always through the skimmers so that the new water passes through the Aquascenic system before entering the pool. Remember to add the necessary salt (1 gr) per added liter of water.
- In winter changing the pool water is not recommendable. We recommend that the system runs 2-3 times per week (2-3 hours per day).
- **5** DOSING PUMPS: Check regularly to ensure that the container contains liquid to prevent the dosing pump of running dry. The dosing pump requires maintenance (SEE INSTRUCTIONS ON BOX).
- B PROBES / redoX / CONDUCTIVITY: Probes must be cleaned whenever necessary (check every 5-6 months). To clean the probe insert in distilled water (clear liquid). After each cleaning the probes must be calibrated. Also: the probes should never dry out and must be kept wet if stored (when emptying the pool for winterizing, make sure to store the measuring head in water).

7 TROUBLESHOOTING



Very Important: Make sure the cell is off while cleaning the filter. If the system controls the filtration pump, use the option "filter cleaning" of the programmed filtration mode. See section 4.4 – Filtration (Filter Cleaning).

VERY IMPORTANT

Remember that the system needs some time to adapt to your pool and that you will have to increase chemical levels for the first 5 days. **EARTHING**

All metallic components in the pool such as lamps, ladders, heat exchangers, drains or similar elements within 3 m from the pool (10 feet) must be connected to an earth below 37 Ohms. If using heat exchangers, we recommend them to be made of titanium.

SECURITY

To avoid accidents, children should not handle this product unless supervised by an adult. Children should be supervised at all times when in or near a spa, pool or jacuzzi.

HANDLING AND DOSING DANGEROUS CHEMICALS

Chemicals should be handled with extreme precaution. When preparing acid, always add acid to water, never add water to acid, because very dangerous gasses may be produced.

